


RUX

Návod k seřízení



Spodní otvory otevřené

k				
RUX				
160	200	250	315	400
8,1	12,2	20,4	28,7	46,8





Zcela otevřeno

k				
RUX				
160	200	250	315	400
14,3	20,2	36,3	49,6	83,4

Boční otvory otevřené

k				
RUX				
160	200	250	315	400
6,2	8,0	15,9	20,9	36,6

Otevření bočních otvorů



* RUX-S – speciální výrobek s uzavřenou spodní deskou.