



SET

Návod k seřízení

Seřízení – zaslepení 1 trysky: **k = -0,2**

SET	k
100	2,4
125	3,6
160	6,7
200	11,1
250	16,6
315	27,2
400	45,2

SAT



SET

